

FASTCAM-Series DRIVER CD-ROM Rev. 2.40.50		Release Note
		2007/07/02
<p>CD-ROM Revision</p> <p>FASTCAM-Series DRIVER CD-ROM Rev.2.40.50 (Domestic/Overseas common shipment version)</p> <p>PFV Revision</p> <p>PFV Ver.2450 SDK Ver.2982</p> <p>The contents of a folder in CD-ROM</p> <p>PFV setup PFVSETUP</p> <p>Driver Device driver</p> <p> FASTCAM-Ultima1024</p> <p> FASTCAM-Ultima SE</p> <p> FASTCAM-PCI</p> <p> FASTCAM-PCI R2</p> <p> FASTCAM-X1280PCI</p> <p> FATSCAM-ultima APX</p> <p> FATSCAM-ultima 512</p> <p> FATSCAM-512PCI</p> <p> FASTCAM-APX RS</p> <p> FASTCAM-1024PCI</p> <p>SDK FASTCAM series correspondence SDK ,Sample code ,SDK document</p> <p>Doc PDF file inclusion of each camera manual ,Release Note</p> <p>DirectX Microsoft DirectX Run time</p>		

Functional addition		Bug fixed	Others
No.	Contents	Hardware Update	
FASTCAM-APX			
1	Bug fixed which had caused failure of gate setting on FASTCAM-APX I.I. cameras (in two-camera operation) if one camera's I.I. power was on and the other's off.		
PFV-SDK			
2	New feature added which displays an hourglass on the screen when the camera is in the Trigger In or Endless Rec mode.		
3	New feature added which enables interpolated display of zoom-in or zoom -out image by bilinear or bicubic interpolation method.		
4	Waveform display drawing function has been speeded up.		
5	Bug fixed which had caused 1 line offset of the crosshair cursor coordinate on the stored image in the crosshair cursor storing mode.		
6	Bug fixed which had caused an abnormal shutdown of application if playback was commanded of a range of no image data recorded when a waveform input board was in use.		
7	Bug fixed which had caused an abnormal shutdown of application when closing the option dialog if Configure was opened and then closed with WMV9 VCB Codec selected in the AVI2.0 storing option dialog.		
8	Bug fixed which had caused a misalignment of the selected area at the end of the mouse drag if the right-hand side was selected when specifying an area with the mouse in the AutoExposure and Variable functions.		
9	Specification changed so that the image rotation display can be forcibly released when image rotation is going on for AutoExposure setting.		

End of documents